

# Thinkpad Disinfection – User Safety

Yes	No
Peroxides (diluted conc. less than 3%)	Chlorines*
Alcohols (Isopropyl less than 70%)	lodophors
Quaternary Ammonium Compounds (tested in solution only)	Phenolics
Peracetic Acid (tested in solution only)	

Covers and display panels passed. Keyboard paint failed

## **Untested**

Ethylene Oxide (EtO)

Formaldehyde / Glutaraldehyde

realthcare Technology: Disinfection Ready to Clean, Ready for Healthcare Prevent Infection on the Front Lines Healthcare settings are full of devices, screens and monitors, all of which can harbor bacteria that lead to infections. That's why cleaning hard surfaces in these environments is critical to controlling the spread of infection and keeping patients and staff healthier. Patient Health is at Stake

- Hospital-acquired infections affect 5%-10% of hospitalized patients in the U.S. per year!
- When healthcare facilities, care teams, and individual doctors and nurses are aware of infection problems and take specific steps to prevent them, rates of some targeted healthcare-acquired infections can decrease by more than 70%,2

'cdc.gox, "Preventing Healthcare Associated Infections" "cdc.gov, "HAIs at a Glance"

To learn more about Lenovo Health and our ready-to-sanitize products, contact your local Lenovo Account Representative or your local Business Partner.

Lenovo Health Technology: Sanitization-Ready for Patient Protection

Lenovo Health products are integral to patient care. That's why our rugged, state-of-the-art devices are tested with medical wipes to achieve more effective infection prevention. While many electronic devices can be corroded by repeated cleaning, our devices stand up to the daily sanitization necessary to achieve more effective infection prevention.

Lenovo Health recommends:

- Use hydrogen peroxide or alcohol-based wipes
- · Do not use bleach-based wipes
- · Wipe away residual solvent



VIrox Accel Wipes with 0.5% hydrogen peroxide



PDI Germicidal Wipes alcohol-based wipes



For more information on how to properly clean Lenovo Health products, visit www.lenovo.com/cleanpc



0.2018 Lenovo. All rights reserved. Lenovo is a trademark of Lenovo in the United States, other countries, or both, Intel, the Intel logo, and intel inside are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. All other trademarks are the property of their respective connex. VLOO May 2018.



Based upon Guideline for Disinfection and Sterilization in Healthcare Facilities (2008)



### More information....

# Keeping you computer clean - publicly accessible link how to proceed with the PC disinfection



Documentation

#### Keeping your computer clean – Notebooks, All-In-One Desktops, Tiny-In-One, and **Monitors**

Use the following information to keep your notebook, tablet, or all-in-one device looking shiny and new.

Note: Remove any media from the drives and turn off all connected devices and the computer. Then, disconnect all power sources such as batteries or power cords from electrical outlets and disconnect all cables that are connected to the computer.

#### Cleaning the cover of your computer

Occasionally clean the exterior of your computer as follows:

- Use only mild cleaning solutions (non-ammonia based and non-abrasive) and a damp lint-free, soft cloth to clean the painted surfaces of the computer.
- Apply non-ammonia based cleaner onto the cloth
- Absorb the cleaner into a sponge or lint-free, soft cloth.
- Squeeze out the excess liquid from the sponge or cloth.
- Wipe the cover using a circular motion taking care not to let any excess liquid drip.
- Wipe the surface to remove any left-over cleaner.
- Rinse the sponge or cloth with clean running water and squeeze out any excess liquid.
- Wipe the cover with the clean sponge or lint-free, soft cloth.
- Wipe the surface again with a dry, lint-free, soft cloth.
- 10. Wait for the surface to dry completely and then remove any fibers left from the sponge or cloth

